



TO EACH TERMINAL OF THE ACTIVE FILTER

TONE CODE

		1	2	3	4	5
OFF	S	R1	2	3	R4	R5
	C	R1	2	3	T4	T5
REPEAT 1	S	R1	2	3	R4	R5
	C	R1	2	3	R4	R5
REPEAT 2	S	R1	2	3	R4	R5
	C	T1(G)	2	3	T4	T5

- Q1~5,7,9~18,20,21 2SC945 2SC828
- Q6,8 2SD227 2SC1317
- Q19 2SA733 2SA564

- D1~23 1S935 1SS53
- 1S1555 1S1588
- D24 MZ309B RD9.1E
- WZ090

**SCHEMATIC DIAGRAM
MODEL SC-S100**